

Technical Specifications

SENSX EXTREME READER

RFID Reader Specifications

Feature	Specification
Product Name	SensX Extreme
Reader Protocol	EPC Class 1 Gen 2 and 18000 – 6C
Operating Frequency	902.75 MHz – 927.25 MHz
Hopping Channels	50
Channel Spacing	500 KHz
Channel Dwell Time	< 0.4 seconds
RF Transmitter	< 30 dBm
Modulation Methods	Phase Reversal – Amplitude Shift Keying (PR-ASK)
	Double Side Band – Amplitude Shift Keying (DB-ASK)
20 dB Modulation Bandwidth	< 100 KHz

Sensors Specifications

Feature	Specification
UHF RFID	EPC Class 1 Gen 2 and 18000- 6C



Antenna and RF Interface Specifications

Feature	Specification
External RF Antenna Ports	4 x RP-TNC
RF Transmit Power (dBm)	+33 dBm
Operating Frequency	902.75 MHz – 927.25 MHz (Region code is field assignable via software)

The reader table refers to US and Canadian specifications only. Reader models released for the other countries may have different power levels, frequency of operation, and channel spacing in compliance with local regulations where the product is sold.

Digital Interface Specifications

Feature	Specification
Ethernet – Data and Power	10/100Base-T TCP/IP; Ethernet
	Rugged IP67 (RJ-45) accepting Class 4 PoE, with dust cap
GPIO (incl. Input power)	2 input, 2 output, optically isolated;
	+12 to +24 VDC input and gnd;
	Rugged IP67 6-pin circular male pin connector with dust cap

Physical and Environmental Specifications

Feature	Specification
Dimensions (I-w-h) including interfaces	(mm) 240 x 55 x 125 / (in) 9.4 x 4.9 x 2.1
Weight	Approximately 1120 g (2.46 lbs)
Operating Temperature	-40°C to +50°C
Operating Environment	100% humidity



Power Specifications

Feature	Specification
	802.3at PoE (25.5 - 30W)
Input Power (PoE)	 RJ-45, Class 4 PD (receive power)
	802.3at Power Injector (P/N SPOE29WC4)
Input Power (VDC)	+12-24 VDC via GPIO connector
Software Support	SensThys Console, SDKs (VB.Net, C# and Java)
Power Consumption (33dBm)	Power into Extreme: 13 to 15W typical

Compliance

Feature	Specification
Compliance Certifications	IP-67 (designed to be compliant)
Compilarios Commisations	UL: Safety tested to UL 60950-1 (pending)
	US: FCC Part 15;
	FCC ID: MAD-RU00-M03
	Australia: ACMA AS NZS 4268
Country Compliance	New Zealand - TBD
	China: CMIIT ID: 2019DJ1414
	Industry Canada: pending



Part Numbers

	Extreme	
North America	SX11480F	
Europe	SX11480E	

Power Supply

SensThys recommends using the shielded SensThys injector (P/N:SP0E29WC4), as it is fully 802.3at compliant.

Sens Thys highly recommends that both shielded PoE injector AND shielded CAT6 cables be used for all Sens Array installations.

Part Number	Description
SPOE29WC4	SensArray, CORD PACK Class 4 Power over Ethernet (PoE+) Power Injector, Shielded







Physical Connections

Extreme Reader with Cap and Chains, Dust covers.




RF Antenna Connectors

The Extreme provides four (4) RP-TNC connectors (pins) on the unit for connecting up to four (4) UHF RF antennas. The connectors are labeled "ANT1", ANT2", ANT3" and "ANT4" from right to left on the unit.

The RP-TNC connectors are covered by cap and chain when not in use.

For most applications standard RF cabling is suggested. However, in extreme conditions, IP-67 compliant RF cables must be used.





Ethernet Connector (labeled "PoE")

The Extreme provides a ruggedized RJ-45 connector for standard Ethernet and PoE+connectivity. The connector is labeled "PoE".

The Ethernet connection is not crossover. It is not auto-MDIX PoE+ port.

The Extreme accepts for 802.3at or Class 4 PoE. (25.5 -30W)

The RJ-45 connector should be covered by the duct cap when not in use.





GPIO (General Purpose Input/Output) Connector

The SensX Extreme GPIO port provides two control inputs and two control outputs, as well as input pin to +24 VDC to power the GPIO outputs.


Two pairs of input/output pins are provided by the GPIO connector. Pinout assignments are below. Both the input and output pins are opto-isolated.

For the GPIO output pins to switch, Pin 5 should be connected to +12 to +24 vdc and external ground to pin 2.

Toggling the external outputs opens or closes an internal transistor switch that allows/prevents current to flow from the voltage applied to the external output pin to ground. (Please see the *Extreme GPIO Deployment Guide* for more information and example circuits.)

Extreme GPIO Pin-out Specifications





Pin Number	Assignment	Description
1	Input No. 2	V<0.5 VDC = "0", 3 <v< 24="" <="" td="" vdc="1"></v<>
•	iliput No. 2	(e.g. 3.3V and 5V digital logic signal ="1")
2	External Ground	
3	Input No. 1	V<0.5 VDC = "0", 3 <v< 24="" <="" td="" vdc="1"></v<>
3	input No. 1	(e.g. 3.3V and 5V digital logic signal ="1")
4	Output No. 2	When Output = "1", V (pin 4) = voltage at Pin 5
5	VCC	GPIO Input voltage (5-24 VDC)*
6	Output No. 1	When Output = "1", V (pin 6) = voltage at Pin 5



Drawings

The Extreme reader dimensions are presented below (in mm):




Figure 1: Dimensions of the Extreme



Coming Features

The hardware and operating system of the Enterprise supports many additional functions and sensors, including GPS (location), WiFi, Bluetooth, BLE Beacon detection, gyroscope and 3-axis accelerometer.

These sensors will be formally introduced in future revisions for Extreme.